

2822 Sable Mill Rd., Jeffersonville, IN 47130 Toll: (877) 338-9403 Fax: (812) 288-7971 https://www.1stsourcebearings.com

Learn how to measure a Hex Bore

(Think of a hex as a clock - DO NOT measure flat to flat.)

- 1. Place one caliper end at the groove (not at the flat) at 6:00
- 2. Place the other caliper end at the groove at either 10:00 or 2:00









